LASVIT SPACEY LUNAR TABLE LAMP MANUAL CE

by Lukáš Novák



Contents

Note

Technical parameters
Step-by-step installation
Light source replacement
Warranties and Warranty Terms and Conditions
Markings
Warning Warns you of high risk of damage to the fixture or injury. Risk of electrical injury. Warns you of high risk of electrical injury should a live part be directly or indirectly touched.
Notice Warns you about possible damage to the fixture. Important Important information regarding the usage of your fixture.
important information regarding the dadge of your fixture.

Gives you general information about the usage of your fixture.

2 6 7 Please read this manual carefully and keep it in case you need assistance while performing maintenance and cleaning procedures.

1/ Technical parameters

Item ID / Spacey CL094TA-1CE

Light source / 1 x E14, max 20W

Input voltage / 220–240V, 50/60Hz

Rated power / max. 20W

Protection rating / IP 20

Safety class / CLASS II

Dimensions / Dia 200 x 295 mm

Weight / approx. 3,5 kg


1


2/ Step-by-step installation

negligent or accidental switching on.


A Before starting any procedures make sure that the power to the lighting fixture is switched OFF and secured against unauthorized,


i Should the cable need to be shortened, ask a qualified technician







Step 2





Step 4





Screw the bulb in the socket clockwise. Use E14 bulb with the following specifications: max. 20W, 220–240V. The manufacturer shall not be held responsible for improper function when other light source is used.

Plug in the lamp to the power grid and switch it on.

5

3/ Light source replacement

All light sources can be supplied by the manufacturer Lasvit s.r.o.

Replacement of the bulb should be carried out by qualified technician to prevent any damage to heath or property. The bulb can be very hot so wait at least 10 minutes until it has cooled down and there is no risk of injury.

Unplug the light from the power grid.

Unscrew the faulty bulb anticlockwise. Screw in the new bulb clockwise. Use E14 bulb with the following specifications: max 20W, 220–240V.

The manufacturer shall not be held responsible for improper function when other light source is used.

Plug in the light again.

4/ Warranties and Warranty Terms and Conditions

- The warranty is defined in Price Quotation (PQ) or in Purchase Agreement (PA). If not stated otherwise, the warranty shall not cover the light sources, maintenance, service and cleaning and the standard warranty shall be set at 2 years. Any other warranties must be specified in PQ or PA. The Customer must submit a valid agreement, invoice or another payment document as a base for any complaint.
- If the warranty covers the detected defect, the Customer shall inform Sales (by e-mail or phone, defining the project / product number, the project / product name, the areas where the defect has emerged, and the sketch number. The Customer shall describe the defect).
- Sales shall proceed based on the internal guideline for complaint management.
- 4. The Manufacturer shall analyze the origins of the defect either at the Customer's or at the Manufacturer's, after the defective product has been delivered to the Manufacturer's premises.
- After the analysis, the decision about acknowledgement or refusal of the complaint and the respective explanation shall be passed on to Sales.
- 6. Sales shall submit information about acknowledgement / refusal of the complaint to the Customer within 7 workdays from reporting the defect at the latest. Sales shall agree further steps with the Customer (e.g. the date of repair, replacement, etc., based on the Customer's and Manufacturer's capacities). Unless agreed otherwise, the Manufacturer shall eliminate any defect within 30 days from the date of submittal of the complaint.
- 7. The complaints shall not cover any defects caused by the Customer, normal wear and tear, or by failure to follow the service manual or installation manual. The complaints shall not cover any defects caused by force majeure.
- 8. The analysis may lead to the following conclusions:


Manufacturer's fault:

• The product is repairable at the Customer's at the Manufacturer's cost.

- The product is repairable at the Manufacturer's at the Manufacturer's cost.
- The product is not repairable and shall be replaced by a tested functional one at the Manufacturer's cost.
- The product is not repairable and the Manufacturer cannot offer any
 replacement. The Manufacturer shall offer another product. The
 Customer shall accept the offer and settle the new product by a
 difference payment, or the Manufacturer shall pay a difference payment
 to the Customer.
- The product is not repairable and the Manufacturer cannot offer any replacement. The Manufacturer shall issue a refund to the Customer.

Customer's fault:

- The product is repairable at the Customer's at the Customer's cost.
- The product is repairable at the Manufacturer's at the Customer's cost.
- The product is not repairable and shall be replaced by a verified and functional one at the Customer's cost.
- The product is not repairable and the Manufacturer cannot offer any replacement. The Manufacturer may offer another product for purchase.





Never dispose of this product in mixed municipal waste, it must be submitted at the designated disposal installation.

The fixture was designed and manufactured by /
Lasvit s.r.o. / Komunardů 32 / 170 00 Praha 7 /
Czech Republic T +420 481 120 810 / F +420 481 120 622 /
E lasvit@lasvit.com lasvit.com

Manual created

16.09.2021

In case you need any assistance or have any suggestion, please contact us at

lasvit.com